

WORKSHOP ON MONTE-CAROL SIMULATIONS-APPLICATIONS IN SCIENCE AND TECHNOLOGY

MAY 15-17, 2017

S.AOGAKI

SCORING IN GEANT4

SENSITIVE DETECTOR AND HITS COLLECTION

BEFORE PRESENTATION

- ▶ I made one example including my talks
- ▶ Please download from
- ▶ <https://github.com/aogaki/Workshop2017>
- ▶ e-mail: sohichiroh.aogaki@nipne.ro

CONTENTS

- ▶ Introduction
- ▶ Sensitive detector and Hits collection
- ▶ How to describe
- ▶ How to obtain some information

INTRODUCTION

INTRODUCTION

- ▶ To obtain some simulation results. We have two ways
 - ▶ Using user hooks (G4UserTrackingAction, G4UserSteppingAction, and etc.)
 - ▶ You can access full information
 - ▶ It is not presented in this presentation
 - ▶ Using scoring functionality (G4VSensitiveDetector)
 - ▶ I will explain about this
 - ▶ My style is very simple

SENSITIVE DETECTOR AND HITS COLLECTION

SENSITIVE DETECTOR AND HITS COLLECTION

- ▶ Sensitive detector
 - ▶ Sensitive detector (`G4VSensitiveDetector`) is assigned to logical volume (`G4LogicalVolume`)
 - ▶ You can choose any volume
 - ▶ Obtaining some informations in `ProcessHits` (user defining function of sensitive detector)
 - ▶ Deposited energy
 - ▶ Position information
 - ▶ Time information
 - ▶ etc.


SENSITIVE DETECTOR AND HITS COLLECTION

- ▶ Hits collection
 - ▶ Like a variable array of hit (G4VHit)
 - ▶ One hits collection means one event
 - ▶ Each hit has the information come from sensitive detector
 - ▶ All information are recorded at the end of event

SENSITIVE DETECTOR AND HITS COLLECTION

- ▶ Each logical volume can have the Sensitive detector
 - ▶ This logical volume becomes detector!
- ▶ Hit is a snapshot of the interaction between particles and the detector
- ▶ In one event, there are so many interaction
- ▶ Hits collection records all interaction in the detector
 - ▶ Sensitive detector make one hit from step (G4Step)

SENSITIVE DETECTOR AND HITS COLLECTION



SENSITIVE DETECTOR AND HITS COLLECTION

- ▶ You can make any kind of detector
 - ▶ Tracking detector?
 - ▶ Recording particle id and position (and momentum)
 - ▶ Calorimeter?
 - ▶ Recording position (or volume information) and deposited energy

HOW TO DESCRIBE (AND USE IT)

HOW TO DESCRIBE AND USE

- ▶ The sensitive detector is assigned for logical volume in DetectorConstruction
- ▶ MySD class uses the name of itself "SD" and Hits collection name "HC".
- ▶ Registering detector to G4SDManager
- ▶ Assignment sensitive detector to logical volume using the name of logical volume

```
void MyDetectorConstruction::ConstructSDandField()
{
    // Sensitive Detectors
    G4VSensitiveDetector *SD = new MySD("SD", "HC");
    G4SDManager::GetSDMpointer()->AddNewDetector(SD);

    G4LogicalVolumeStore *lvStore = G4LogicalVolumeStore::GetInstance();
    for(auto &&lv: *lvStore){
        if(lv->GetName().contains("LGSORow") ||
           lv->GetName().contains("NaI"))
            SetSensitiveDetector(lv->GetName(), SD);
    }
}
```

HOW TO DESCRIBE AND USE


- ▶ SensitiveDetector file
- ▶ Initialize()
 - ▶ Registering my hits collection with ID number
 - ▶ It will be used at the end of an event
- ▶ Inside the ProcessHits is next slide

```
MySD::MySD(const G4String &name,
           const G4String &hitsCollectionName)
    : G4VSensitiveDetector(name)
{
    collectionName.insert(hitsCollectionName);
}

void MySD::Initialize(G4HCofThisEvent *hce)
{
    fHitsCollection
        = new MyHitsCollection(SensitiveDetectorName, collectionName[0]);

    G4int hcID
        = G4SDManager::GetSDMpointer()->GetCollectionID(collectionName[0]);
    hce->AddHitsCollection(hcID, fHitsCollection);
}

G4bool MySD::ProcessHits(G4Step *step, G4TouchableHistory /*history*/)
{
    // Obtaining some information
    // and making Hit
}
```



G4CollectionNameVector

HOW TO DESCRIBE AND USE

- ▶ G4Track means all track
- ▶ G4StepPoint means end and start points of step
- ▶ Usually, we use the information from PostStepPoint
- ▶ We need the information after interaction

```
G4bool MySD::ProcessHits(G4Step *step, G4TouchableHistory /*history*/)
{
    G4Track *track = step->GetTrack();
    G4int trackID = track->GetTrackID();
    //if(trackID != 1) return false; // only the primal particle

    MyHit *newHit = new MyHit();

    newHit->SetTrackID(trackID);

    G4StepPoint *postStepPoint = step->GetPostStepPoint();
    G4ThreeVector position = postStepPoint->GetPosition();
    newHit->SetPosition(position);


    G4ThreeVector momentum = postStepPoint->GetMomentum();
    newHit->SetMomentum(momentum);

    G4StepPoint *preStepPoint = step->GetPreStepPoint();
    G4String volumeName = preStepPoint->GetPhysicalVolume()->GetName();
    newHit->SetVolumeName(volumeName);

    fHitsCollection->insert(newHit);
    return true;
}
```


HOW TO DESCRIBE AND USE

- ▶ **Attention!**
- ▶ The volume name should be taken from PreStepPoint
- ▶ PostStepPoint is at Volume2
- ▶ Interaction is in Volume1



```
G4bool MySD::ProcessHits(G4Step *step, G4TouchableHistory /*history*/)
{
    G4Track *track = step->GetTrack();
    G4int trackID = track->GetTrackID();
    //if(trackID != 1) return false; // only the primal particle

    MyHit *newHit = new MyHit();

    newHit->SetTrackID(trackID);

    G4StepPoint *postStepPoint = step->GetPostStepPoint();
    G4ThreeVector position = postStepPoint->GetPosition();
    newHit->SetPosition(position);

    G4ThreeVector momentum = postStepPoint->GetMomentum();
    newHit->SetMomentum(momentum);

    G4StepPoint *preStepPoint = step->GetPreStepPoint();
    G4String volumeName = preStepPoint->GetPhysicalVolume()->GetName();
    newHit->SetVolumeName(volumeName);

    fHitsCollection->insert(newHit);
    return true;
}
```


HOW TO DESCRIBE AND USE

```
class MyHit : public G4VHit
{
public:
    MyHit();
    virtual ~MyHit();
    MyHit(const MyHit &right);
    const MyHit &operator=(const MyHit &right);
    int operator==(const MyHit &right) const;

    inline void *operator new(size_t);
    inline void operator delete(void *);

    // add setter/getter methods
    void SetTrackID(G4int id) {fTrackID = id;};
    G4int GetTrackID() {return fTrackID;};

    void SetPosition(G4ThreeVector pos) {fPosition = pos;};
    G4ThreeVector GetPosition() {return fPosition;};

    void SetMomentum(G4ThreeVector p) {fMomentum = p;};
    G4ThreeVector GetMomentum() {return fMomentum;};

    void SetVolumeName(G4String volumeName) {fVolumeName = volumeName;};
    G4String GetVolumeName() {return fVolumeName;};

private:
    G4int fTrackID;
    G4ThreeVector fPosition;
    G4ThreeVector fMomentum;
    G4String fVolumeName;
};
```

- ▶ Hit and Hits collection file
- ▶ Hit class has setter and getter methods
- ▶ In the same file my Hits collection class is also defined

```
typedef G4THitsCollection<MyHit> MyHitsCollection;

extern G4ThreadLocal G4Allocator<MyHit> *MyHitAllocator;

inline void *MyHit::operator new(size_t)
{
    if (!MyHitAllocator)
        MyHitAllocator = new G4Allocator<MyHit>;
    return (void *)MyHitAllocator->MallocSingle();
}

inline void MyHit::operator delete(void *hit)
{
    MyHitAllocator->FreeSingle((MyHit *) hit);
}

#endif
```

HOW TO DESCRIBE AND USE

- ▶ For multi threading, G4Allocator should be G4ThreadLocal
 - ▶ Simply say, MyHitAllocator will be made for each thread
- ▶ This definition of **new** and **delete** operator is a good trick
 - ▶ If using **new** and **delete** at each hit, the computational cost of it is very big
 - ▶ Thus, **delete** don't delete memory space
 - ▶ And, **new** uses recycled memory space
- ▶ Hit and Hits collection file
- ▶ Hit class has setter and getter methods
- ▶ In the same file my Hits collection class is also defined

```
typedef G4THitsCollection<MyHit> MyHitsCollection;

extern G4ThreadLocal G4Allocator<MyHit> *MyHitAllocator;

inline void *MyHit::operator new(size_t)
{
    if (!MyHitAllocator)
        MyHitAllocator = new G4Allocator<MyHit>;
    return (void *)MyHitAllocator->MallocSingle();
}

inline void MyHit::operator delete(void *hit)
{
    MyHitAllocator->FreeSingle((MyHit *) hit);
}

#endif
```

HOW TO DESCRIBE AND USE

- ▶ Event action
- ▶ Before the ned of event

```
MyEventAction::MyEventAction()  
    : G4UserEventAction(),  
      fHitsCollectionID(-1)  
{  
}  
  
MyEventAction::~~MyEventAction()  
{  
}  
  
MyHitsCollection *MyEventAction::GetHitsCollection(G4int hcID, const G4Event *event)  
const  
{  
    MyHitsCollection *hitsCollection  
        = static_cast<MyHitsCollection *>(  
            event->GetHCofThisEvent()->GetHC(hcID));  
  
    if ( ! hitsCollection ) {  
        // Some error handling  
    }  
  
    return hitsCollection;  
}  
  
void MyEventAction::BeginOfEventAction(const G4Event *)  
{  
}
```

HOW TO DESCRIBE AND USE

- ▶ EndOfEventAction
- ▶ I record information hit by hit (step by step)
- ▶ You can do event by event
- ▶ For example, summing all deposited energy

```
void MyEventAction::EndOfEventAction(const G4Event *event)
{
    if (fHitsCollectionID == -1)
        fHitsCollectionID = G4SDManager::GetSDMpointer()->GetCollectionID("HC");

    MyHitsCollection *hc = GetHitsCollection(fHitsCollectionID, event);

    G4int eventID = event->GetEventID();

    G4AnalysisManager *anaMan = G4AnalysisManager::Instance();

    const G4int kHit = hc->entries();
    for (G4int iHit = 0; iHit < kHit; iHit++) {
        MyHit *newHit = (*hc)[iHit];

        anaMan->FillNtupleIColumn(0, 0, eventID); // EventID

        G4int trackID = newHit->GetTrackID();
        anaMan->FillNtupleIColumn(0, 1, trackID);

        G4String volumeName = newHit->GetVolumeName();
        anaMan->FillNtupleSColumn(0, 2, volumeName);

        G4ThreeVector position = newHit->GetPosition();
        anaMan->FillNtupleDColumn(0, 3, position.x());
        anaMan->FillNtupleDColumn(0, 4, position.y());
        anaMan->FillNtupleDColumn(0, 5, position.z());

        G4ThreeVector momentum = newHit->GetMomentum();
        anaMan->FillNtupleDColumn(0, 6, momentum.x());
        anaMan->FillNtupleDColumn(0, 7, momentum.y());
        anaMan->FillNtupleDColumn(0, 8, momentum.z());

        anaMan->AddNtupleRow(0);
    }
}
```

HOW TO DESCRIBE AND USE

- ▶ Run action
- ▶ Simply, Before run, making Ntuple
- ▶ After run, file writing

```
#include "g4root.hh"
void MyRunAction::BeginOfRunAction(const G4Run *)
{
    G4AnalysisManager *anaMan = G4AnalysisManager::Instance();
    G4String fileName = "result";
    anaMan->OpenFile(fileName);

    // Interaction
    anaMan->CreateNtuple("hits", "test detector");
    anaMan->CreateNtupleIColumn(0, "EventID");
    anaMan->CreateNtupleIColumn(0, "TrackID");
    anaMan->CreateNtupleSColumn(0, "VolumeName");

    anaMan->CreateNtupleDColumn(0, "x");
    anaMan->CreateNtupleDColumn(0, "y");
    anaMan->CreateNtupleDColumn(0, "z");

    anaMan->CreateNtupleDColumn(0, "vx");
    anaMan->CreateNtupleDColumn(0, "vy");
    anaMan->CreateNtupleDColumn(0, "vz");

    // Init parameters
    anaMan->CreateNtuple("InitPar", "Initial Parameters");
    anaMan->CreateNtupleIColumn(1, "EventID");
    anaMan->CreateNtupleIColumn(1, "PDGCode");
    anaMan->CreateNtupleDColumn(1, "KineticEnergy");
    anaMan->CreateNtupleDColumn(1, "vx");
    anaMan->CreateNtupleDColumn(1, "vy");
    anaMan->CreateNtupleDColumn(1, "vz");

    anaMan->FinishNtuple();
}

void MyRunAction::EndOfRunAction(const G4Run *)
{
    G4AnalysisManager *anaMan = G4AnalysisManager::Instance();
    anaMan->Write();
    anaMan->CloseFile();
}
```


HOW TO OBTAIN SOME INFORMATION (EXAMPLES)

HOW TO OBTAIN SOME INFORMATION (EXAMPLES)

- ▶ The list of information
- ▶ Particle information
 - ▶ Global and local position
 - ▶ Track ID and ParentID
 - ▶ PDG code and particle name
 - ▶ Momentum
 - ▶ Kinetic energy
 - ▶ Vertex volume name

HOW TO OBTAIN SOME INFORMATION (EXAMPLES)

- ▶ The list of information
- ▶ Particle information
 - ▶ Global and local position
 - ▶ Global means position in whole setup
 - ▶ Local means position in the logical volume
 - ▶ You can obtain its from pre step point (GetPreStepPoint())

```
G4bool MySD::ProcessHits(G4Step *step, G4TouchableHistory /*history*/)
{
    G4StepPoint *postStepPoint = step->GetPostStepPoint();

    G4ThreeVector position = postStepPoint->GetPosition();
    newHit->SetPosition(position);
    G4TouchableHandle theTouchable = postStepPoint->GetTouchableHandle();
    G4ThreeVector localPosition = theTouchable->GetHistory()->
        GetTopTransform().TransformPoint(position);
}
```


HOW TO OBTAIN SOME INFORMATION (EXAMPLES)

- ▶ The list of information

- ▶ Particle information

- ▶ Track ID

- ▶ 1 is primal

- ▶ More than 2 means daughter particles

- ▶ Parent ID

- ▶ The parent of primal particle is 0

```
G4bool MySD::ProcessHits(G4Step *step, G4TouchableHistory /*history*/)
{
    G4Track *track = step->GetTrack();
    G4int trackID = track->GetTrackID();
    G4int parentID = track->GetParentID();
}
```

HOW TO OBTAIN SOME INFORMATION (EXAMPLES)

- ▶ The list of information
- ▶ Particle information
 - ▶ PDG code and particle name

```
G4bool MySD::ProcessHits(G4Step *step, G4TouchableHistory /*history*/)
{
    G4Track *track = step->GetTrack();
    G4ParticleDefinition *particle = track->GetDefinition();
    G4int pdgCode = particle->GetPDGEncoding();
    G4String parName = particle->GetParticleName();
}
```

HOW TO OBTAIN SOME INFORMATION (EXAMPLES)

- ▶ The list of information
- ▶ Particle information
 - ▶ Momentum
- ▶ Also you can take from pre step point

```
G4bool MySD::ProcessHits(G4Step *step, G4TouchableHistory /*history*/)
{
    G4StepPoint *postStepPoint = step->GetPostStepPoint();
    G4ThreeVector momentum = postStepPoint->GetMomentum();
}
```

HOW TO OBTAIN SOME INFORMATION (EXAMPLES)

- ▶ The list of information
- ▶ Particle information
 - ▶ Kinetic energy

```
G4bool MySD::ProcessHits(G4Step *step, G4TouchableHistory /*history*/)
{
    G4StepPoint *postStepPoint = step->GetPostStepPoint();
    G4double kineticEnergy = postStepPoint->GetKineticEnergy();
}
```

HOW TO OBTAIN SOME INFORMATION (EXAMPLES)

- ▶ The list of information
- ▶ Particle information
 - ▶ Vertex volume name
- ▶ Sometime, this helps to find the noise source

```
G4bool MySD::ProcessHits(G4Step *step, G4TouchableHistory /*history*/)
{
    G4Track *track = step->GetTrack();
    G4String vertexName = track->GetLogicalVolumeAtVertex()->GetName();
}
```

HOW TO OBTAIN SOME INFORMATION (EXAMPLES)

- ▶ The list of information
- ▶ Volume information
 - ▶ Volume name
 - ▶ Step point is boundary or not
 - ▶ Deposited energy
 - ▶ Copy number of volume

HOW TO OBTAIN SOME INFORMATION (EXAMPLES)

- ▶ The list of information

- ▶ Volume information

- ▶ Volume name

- ▶ It should be taken from pre step point

```
G4bool MySD::ProcessHits(G4Step *step, G4TouchableHistory /*history*/)
{
    G4StepPoint *preStepPoint = step->GetPreStepPoint();
    G4String volumeName = preStepPoint->GetPhysicalVolume()->GetName();
}
```

HOW TO OBTAIN SOME INFORMATION (EXAMPLES)

- ▶ The list of information
- ▶ Volume information
 - ▶ Step point is boundary or not
 - ▶ If pre step point is boundary, It means incident point
 - ▶ If post step point is boundary, it means particle is exit from volume

```
G4bool MySD::ProcessHits(G4Step *step, G4TouchableHistory /*history*/)
{
    G4StepPoint *postStepPoint = step->GetPostStepPoint();
    G4int isExit = (postStepPoint->GetStepStatus() == fGeomBoundary);
    if(isExit == 0) return false; // only going out particle
    MyHit *newHit = new MyHit();
    newHit->SetIsExit(isExit);

    G4StepPoint *preStepPoint = step->GetPreStepPoint();
    if(preStepPoint->GetStepStatus() == fGeomBoundary){
        G4double incidentEnergy = preStepPoint->GetKineticEnergy();
        newHit->SetIncidentEnergy(incidentEnergy);
    }
    else newHit->SetIncidentEnergy(0.);
}
```


HOW TO OBTAIN SOME INFORMATION (EXAMPLES)

- ▶ The list of information
- ▶ Volume information
- ▶ Deposited energy

```
G4bool MySD::ProcessHits(G4Step *step, G4TouchableHistory /*history*/)
{
    G4double depositEnergy = step->GetTotalEnergyDeposit();
    newHit->SetDepositEnergy(depositEnergy);
}
```

HOW TO OBTAIN SOME INFORMATION (EXAMPLES)

- ▶ The list of information
- ▶ Volume information
 - ▶ Copy number
 - ▶ It is useful for like a SciFi detector
 - ▶ This number represents the which fiber
 - ▶ Of course, you have to set the number, when you construct the volume

```
G4bool MySD::ProcessHits(G4Step *step, G4TouchableHistory /*history*/)
{
    if(volumeName == "LGSORow") {
        G4TouchableHandle touch = preStepPoint->GetTouchableHandle();
        G4int copyNo = touch->GetCopyNumber();
        G4int motherCopyNo = touch->GetCopyNumber(1);
        G4cout << motherCopyNo <<"\t"<< copyNo << G4endl;
    }
}
```

CONCLUSION

- ▶ Sensitive detector (SD) is assigned in Detector construction class
- ▶ SD needs the name of Hits collection (HC), when it is registered
- ▶ User defines ProcessHits member function of SD
 - ▶ It takes some information as Hit
 - ▶ Each Hit is added to HC
- ▶ End of each event, HC is read and its information are filled into an output file
- ▶ When simulation is finished, all information is written in the output file

APPENDIX: HOW TO ANALYZE BY ROOT

- ▶ Using ROOT
- ▶ Making a 2D histogram showing the projection of interaction position and deposited energy at NaI detector
- ▶ First, making simulation data
- ▶ The working directory is Workshop2017
- ▶ After compiling example and running example with 1 million events

APPENDIX: HOW TO ANALYZE BY ROOT

- ▶ Using chain and make analyzer class
- ▶ root [0]: defining TChain and setting ntuple name
- ▶ root[1]: Adding ROOT file
- ▶ root[2]: Making files

```
HappyNatty:Workshop2017 aogaki$ cd samples/  
HappyNatty:samples aogaki$ root
```

```
-----  
| Welcome to ROOT 6.09/01                                     http://root.cern.ch |  
|                                                            (c) 1995-2016, The ROOT Team |  
| Built for macosx64                                         |  
| From heads/master@v6-09-01-1515-g201dc83298, Feb 15 2017, 13:52:00 |  
| Try '.help', '.demo', '.license', '.credits', '.quit'/'.'q' |  
-----
```

```
root [0] TChain *chain = new TChain("hits");  
root [1] chain->Add("../result_t*.root");  
root [2] chain->MakeSelector("MyAnalyzer")  
(int) 0  
root [3] .q
```

APPENDIX: HOW TO ANALYZE BY ROOT

- ▶ MyAnalysis.C and MyAnalysis.h are created by ROOT
- ▶ runAnalyzer.cpp runs MyAnalysis

```
HappyNutty:samples aogaki$ ls  
MakeROOTfile.cpp  MyAnalyzer.h  
MyAnalyzer.C      runAnalyzer.cpp
```

APPENDIX: HOW TO ANALYZE BY ROOT

- ▶ runAnalyzer.cpp loads files and run MyAnalysis
- ▶ Using TProofLite
- ▶ TProofLite is the class of multi-threading

```
#include <TChain.h>
#include <TProof.h>
#include <TProofLite.h>

void ActivatePROOF(TChain *chain, Int_t nThreads = 0)
{
    TProof *proof = TProof::Open("");
    proof->SetProgressDialog(kFALSE);
    if(nThreads > 0) proof->SetParallel(nThreads);

    chain->SetProof();
}

void runAnalyzer()
{
    TChain *chain = new TChain("hits");
    chain->Add("../result_t*.root");
    ActivatePROOF(chain);

    chain->Process("MyAnalyzer.C+O");
}
```

APPENDIX: HOW TO ANALYZE BY ROOT

- ▶ Defining a histogram
- ▶ It should be nullptr at Begin()
- ▶ In SlaveBegin(), it is created
- ▶ GetOutputList()->Add(fHisNaI); is needed to save
- ▶ In Terminate, the histogram is written and saved

```
class MyAnalyzer : public TSelector {
public :
    ...
    TH1D *fHisNaI;
    ...
};
```

MyAnalyzer.h

```
void MyAnalyzer::Begin(TTree * /*tree*/)
{
    ...
    fHisNaI = nullptr;
}

void MyAnalyzer::SlaveBegin(TTree * /*tree*/)
{
    ...
    fHisNaI = new TH1D("HisNaI", "test", 200, -20., 0.);
    fHisNaI->SetXTitle("z [mm]");
    fHisNaI->SetYTitle("Deposited energy [MeV]");
    GetOutputList()->Add(fHisNaI);
}

void MyAnalyzer::Terminate()
{
    ...
    TFile *file = new TFile("output.root", "RECREATE");
    fHisNaI->Write();
    file->Close();
}
```

MyAnalyzer.C

APPENDIX: HOW TO ANALYZE BY ROOT

- ▶ Analyzing
- ▶ If volume name is NaI
- ▶ Recording depth and deposited energy

```
Bool_t MyAnalyzer::Process(Long64_t entry)
{
    ...
    TString detName = &(VolumeName[0]);
    if(detName == "NaI") {
        fHisNaI->Fill(*z, *DepositEnergy);
    }
    ...
}
```

APPENDIX: HOW TO ANALYZE BY ROOT

- Finally, you obtain the result

